



A. H. BEARD
PREMIUM SLEEP SINCE 1899

Fact Sheet

Measuring Body Impressions

How to measure body impressions

Using either a string line, rule, tape measure or flat piece of straight edge such as broom handle lay it across the width of the mattress. Please note, the broom handle must reach both sides of the mattress, we also advise that the measurement is done on the floor as the base could be the cause of the impressions.



How to correctly take measurements

Using a rule, place the end on the panel and read the measurement from underneath the line of the rule, string line, tape measure or broom, this will give you the most accurate measurement, if photos are supplied incorrectly, we may request them to be taken again.



Correct way to measure

Incorrectly taking of measurements

When measuring body impressions, measure at the deepest part of the impression. **DO NOT** measure into a sewing pattern as shown below, these are designed to be lower than the crown or raised panel and will be an inaccurate account of the depth and may not be accepted for your claim.



Incorrect way to measure